

Working with Motion Studio

AC Servo Drive





TABLE OF CONTENTS

INTRODUCTION	4
GETTING STARTED WITH MOTION STUDIO.....	5
CONNECT TO SERVO DRIVE.....	7
PULL-DOWN MENU.....	8
<i>System.....</i>	<i>8</i>
<i>Functions.....</i>	<i>8</i>
<i>Language</i>	<i>8</i>
<i>Tools.....</i>	<i>9</i>
<i>About</i>	<i>11</i>
NAVIGATION TREE	12
SETUP WIZARD.....	12
<i>Parameter Wizard.....</i>	<i>12</i>
<i>Single Parameter Tuning.....</i>	<i>16</i>
CONFIGURATION.....	23
<i>Control Mode</i>	<i>23</i>
<i>Current loop (Torque loop).....</i>	<i>24</i>
<i>Motor Config.....</i>	<i>24</i>
<i>Brake Config.....</i>	<i>25</i>
<i>Limits.....</i>	<i>25</i>
<i>Alarm limits.....</i>	<i>26</i>
<i>Electronic Gear Ratio</i>	<i>26</i>
<i>IO Settings.....</i>	<i>27</i>
<i>Position loop</i>	<i>27</i>
<i>Velocity loop.....</i>	<i>28</i>
<i>Parameters List</i>	<i>29</i>
PERFORMANCE TUNING.....	31
<i>Inertia Ratio Identification.....</i>	<i>31</i>
<i>Gain Adjustment</i>	<i>33</i>
<i>Mechanical Analysis.....</i>	<i>34</i>
RUNNING	35
<i>Trial Run.....</i>	<i>35</i>
MONITOR.....	37
<i>Scope.....</i>	<i>37</i>
<i>Alarm</i>	<i>38</i>
<i>State Monitor.....</i>	<i>39</i>
ETHERCAT	40
<i>Object Dictionary</i>	<i>40</i>
<i>402 observer</i>	<i>42</i>
<i>Diagnostics.....</i>	<i>42</i>

Before we start

Please prepare the following items before we start to work with Motion Studio.

1. Leadshine AC Servo Drive (EL6/ELP/EL7 Series)
2. Leadshine AC Servo Motor (Recommended by Leadshine to be matched with driver)
3. Data cable
 - a. Ethernet-to-DB9 female – For EL6 series AC servo drives
 - b. Mini-USB – For ELP/EL7 series AC servo drives

(Please mind that a charging cable might not be able to transfer data.)
4. Motor power cables (**Direct** or **Aviation** connector depending on motor models)
5. Encoder cables(**Direct** or **Aviation** connector depending on motor models)
6. Motion Studio. Can be downloaded on our website www.leadshine.com

System requirement to run Motion Studio

Operating system: Windows XP or above

CPU: 1.5GHz or above

RAM: 256MB or above

Hard disk capacity: 10GB or above

Display: Resolution 1024*768, color 24 bit


Communication interface: USB Type-A series adapter

Introduction

Motion Studio is a free-to-use software developed by Leadshine Technology Co., Ltd. for simple commissioning of Leadshine AC servo products. Through Motion Studio, users can connect the drivers to PC for parameters reading & writing, system performance tuning, trial run, driver status & data monitoring and much more. Most of the functions can be realized without connecting the driver to a main power supply.

There is no need to install Motion Studio. Download “MotionStudio_ACservo” for designated Leadshine products on our website and unzip the file. Click on MotionStudio.exe to start the software. User manual for Motion Studio can be found in Help folder. It is recommended to save Motion Studio in other disks than C: drive.


<https://www.leadshine.com/download/Software.html>



The screenshot shows the Leadshine website's navigation bar. The "Downloads" button is highlighted with a red border. Below the navigation bar, there are four categories: Catalogs, Manuals, Software (which is also highlighted with a red border), and Certifications.

Getting started with Motion Studio

After unzipping “MotionStudio_ACServer”, click on  MotionStudio.exe to start Motion Studio.



Motion Studio Workspace

① Motion Studio software version


② Pull-down menu

System	<ul style="list-style-type: none"> ▪ To connect to servo drives ▪ To exit software
Functions	<ul style="list-style-type: none"> ▪ To save modified parameters ▪ To reset software ▪ To login to admin's rights
Languages	<ul style="list-style-type: none"> ▪ To switch between Chinese and English display languages
Tools	<ul style="list-style-type: none"> ▪ Serial Port Tool ▪ USB Tool ▪ Object Dict Tool ▪ Register Tool
About	<ul style="list-style-type: none"> ▪ Platform info ▪ User manual

③ Quick Access buttons

	Connect	<ul style="list-style-type: none"> To connect or disconnect servo drives in online or offline mode To check information of connected servo products
	Parameters List	<ul style="list-style-type: none"> To read/write, modify, compare servo drive parameters To save parameters files as backup. To restore parameters back to factory default
	Object Dictionary	<ul style="list-style-type: none"> To read/write, modify, compare servo drive objects. To save object dictionary as backup To configure PDO To restore objects back to factory default.
	Trial Run	<ul style="list-style-type: none"> To test run servo products after connected to driver and motor (Need to connect to main power supply) To run inertia identification
	Scope	<ul style="list-style-type: none"> To capture driver data waveforms To read captured driver's data
	Alarm Info	<ul style="list-style-type: none"> To check current occurrence of error or alarm historical records To check the cause(s) of motor stops running

④ Navigation tree



Driver model no. will appear on top of the navigation tree. Branches of the navigation tree will adapt according to the communication protocol of the connected servo drive. For example, servo drives with EtherCAT communication protocol will only have EtherCAT appearing on the navigation tree.


Branches and their extension functions will be explained in following chapters of the manual.

⑤ Status bar

Comm	To show connection status of the servo drive <ul style="list-style-type: none"> Standby (Red) – No driver connected yet Online (Green) – Driver successfully connected.
Servo	To show the status of the servo drive <ul style="list-style-type: none"> Disable (Red) – Servo drive is powered-off. Enable (Green) - Servo drive is powered-on.
Alarm	To show alarm status <ul style="list-style-type: none"> None (Green) – No alarm Other (Red) – Servo error occurs.

Connect to Servo Drive

1. Click on .
2. “Connect” pop-up window will appear.




①	<ul style="list-style-type: none"> ▪ Online mode: Driver and motor connecting to USB port automatically identified ▪ Offline mode: Use offline mode to read parameters saved in PC.
②	<ul style="list-style-type: none"> ▪ Only RS232 communication mode is supported for the moment being. ▪ Communication Port can be automatically identified by clicking on “Refresh”. If driver failed to connect, please verify data cable or change to another USB port. ▪ Check “Adaptive Baud rate” and click on “Connect” to connect to servo products. <p><i>Driver can be connected to PC without main power supply.</i></p>
③	<ul style="list-style-type: none"> ▪ Servo products info such as series, model no., ports, axis count and firmware version can be found here.



3. When servo drive is connected to PC through data cable, **USb** will appear on the front panel of the servo drive. Err0D2 will appear due to no main power supply connected, it doesn't affect most tuning works of the servo drive.
 4. Once successfully connected, Comm on status bar will turn green with "Comm: Online".
- Comm: Online**
5. Connect window will close automatically in 3s after successfully connected.
 6. If connection failed, please verify:
 - a. Data cable. Charging cable might not be able to transfer data.
 - b. Change another USB port.
 - c. Any alarm error which needs to be reset.

Pull-down Menu


System




Functions



Language



Tools



Tools

Communication:

Port: COM1	Baudrate: 38400	Databit: 8	Stopbit: 1	Parity: None	State: Close	Open
------------	-----------------	------------	------------	--------------	--------------	------

NO.: 01 Read: 01 Address: 20 Return HEX: DEC: BIN: Send

NO.: 01 Read: 01 Address: 21 Return HEX: DEC: BIN: Send

NO.: 01 Read: 01 Address: 22 Return HEX: DEC: BIN: Send

NO.: 01 Read: 01 Address: 23 Return HEX: DEC: BIN: Send

NO.: 01 Read: 01 Address: 24 Return HEX: DEC: BIN: Send

NO.: 01 Read: 01 Address: 25 Return HEX: DEC: BIN: Send

NO.: 01 Read: 01 Address: 26 Return HEX: DEC: BIN: Send

NO.: 01 Read: 01 Address: 27 Return HEX: DEC: BIN: Send

NO.: 01 Read: 01 Address: 28 Return HEX: DEC: BIN: Send

NO.: 01 Read: 01 Address: 29 Return HEX: DEC: BIN: Send

Save Settings



USB Debug Tool

Init

Driver No.: 63

Address(Dec): 00

Simple R/W

Return: Read

Write: Return: Write

Batch Size R/W

len = 0 Read

(Hex) len = 0 Write

Object Dictionary Tool

Object Dictionary Region

Index(HEX) 6060 SubIndex(HEX) 00

Value(HEX) Value(DEC) Error Code(HEX)

Object Dictionary Region 1

Index(HEX) 6041 SubIndex(HEX) 00

Value(HEX) Value(DEC) Error Code(HEX) Continuous read

Object Dictionary Region 2

Index(HEX) 6064 SubIndex(HEX) 00

Value(HEX) Value(DEC) Error Code(HEX) Continuous read


Register Tool

Register Region

Address(HEX) 0 Value(HEX) Value(DEC)

Continuous read

About



Navigation tree


Setup Wizard




Parameter Wizard

Step-by-step guide to set up servo drives. Most of the parameters are automatically identified and set to default value once servo drive + motor is connected but users may need some customizations to servo parameters and settings.


1. Start screen of Parameter wizard consists of basic information of the servo products, I/O interfaces and setup menu on the left. Click on “Start” to start servo parameters setup.




2. On motor selection page, user can find out more about motor and encoder specifications. Users are not recommended to modify any parameters on this page as it might cause abnormal behavior of the driver or motor. Click on “Next” to go to the next page or “Previous” to go back to previous page.




3. On control mode page, control mode of the driver is automatically identified. Click on “Next” to go to the next page or “Previous” to go back to previous page.




4. On command source page, set up slave ID source. Click on “Next” to go to the next page or “Previous” to go back to previous page.




5. On Electronic Gear Ratio page, users can choose between setting pulses per revolution or electronic gear ratio. Calculation formulas are provided. Click on “Next” to go to the next page or “Previous” to go back to previous page.




6. On Encoder Output page, users can set up encoder pulse output per revolution (= *Pulses per revolution/4*) and pulse logic. Click on “Next” to go to the next page or “Previous” to go back to previous page.



7. On IO settings page, users can allocate DI/DO signals to selected channels. Click on “Next” to go to the next page or “Previous” to go back to previous page.



8. On Save page, users can save modified parameters. Click on “Next” to go to the next page or “Finish” to complete setup.




Single Parameter Tuning

Set a mechanical stiffness level and the driver will automatically tune the parameters accordingly, including inertia measuring and vibration suppression to fulfill responsiveness and stability needs. At same time, more advanced functions can be applied, for example: Command pulse filter, low frequency vibration suppression, etc.


Recommended for applications where inertia changes is minute. Single parameter tuning is more complicated to set up compared to one-click tuning. Use single parameter tuning when one-click tuning doesn't fulfill the needs.

Easy Mode

- Click on “Single Parameter Tuning” under Setup Wizard. Choose “Enable automatic inertia identification” and “Enable automation vibration identification”. If the system is heavily loaded with Pr0.03 mechanical stiffness value lower than 70, by selecting “Set low stiffness”, initial Pr0.03 value in Single Parameter Tuning will start at 70.



- Set the value of MFC bandwidth, stiffness as per the table below under Easy Setup.




MFC bandwidth set value	Description
0	Deactivate model-following control function
【1】	Automatically adjust MFC bandwidth
2~9	Invalid
10~2000	Manually adjust MFC bandwidth; Recommended 30-100 for transportation belt applications

Stiffness level goes from 81-50 with 50 being highest stiffness level. Velocity response improves with higher stiffness level but vibration might occur. For flexible structures, decrease stiffness level and setup vibration suppression.

3. Resonance automatic settings: Automatically identified vibration under actual stiffness level settings. Default value is restored when no vibration is detected. If not selected, value will not be restored to default.

Advanced mode

4. Set Tuning mode.



Load tuning type

Rigid body: Structure with low flexibility (i.e. screw leads)

High Inertia: 30-40 times higher than load inertia.

Flexible body: Low stiffness (i.e. belt)

Motion tuning type

Manual: Auto adjustment off. Parameters under Easy Setup available to be modified.


Standard: Prioritize stability. No switch gaining.

Location: Recommended for horizontal axis with variable load or ball screw structures.

5. Inertia identification is automatically enabled at the start.

Identification value (%): Inertia ratio will be automatically identified with yellow box blinking on every successful identification

Current value (%): If “Automatic setting” is selected, inertia ratio will be automatically synchronize to Pr0.04. If not selected, user can press Enter to set the value to Pr0.04.



6. Vibration suppression: Notch filter

Torque vibration amplitude: 0% - Max. sensitivity, 100% - Deactivated (*Adjust accordingly*)

Suppression mode: 0 – Adaptive notch filter **deactivated**

1 – Adaptive notch filter **valid for once**


2 – Adaptive notch filter **always valid**

Notch filter: 1st, 2nd and 3rd notch filter

Frequency(Hz): 50~2000


Width: 0~20

Depth: 0~99



Vibration suppression: Command filtering

(These parameters are manually set, cannot be automatically identified.)



Parameter	Range(Unit)	Description
Position command smoothing filter	0~32767(0.1ms)	Large set value might elongate tuning time
Position command FIR filter	0~10000(0.1ms)	
1 st damping frequency	10~2000(0.1Hz)	
2 nd damping frequency	10~2000(0.1Hz)	To suppress mechanical end vibration

Vibration suppression: Higher-order Parameters

3. Vibration suppression

Command filtering	Higher-order parameter												
<table border="1"> <thead> <tr> <th>Label</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Velocity observer gain(--)</td> <td>0</td> </tr> <tr> <td>Velocity observer bandwidth(ms)</td> <td>0</td> </tr> <tr> <td>Current response settings(%)</td> <td>0</td> </tr> <tr> <td colspan="2"> </td> </tr> <tr> <td colspan="2"> </td> </tr> </tbody> </table>		Label	Value	Velocity observer gain(--)	0	Velocity observer bandwidth(ms)	0	Current response settings(%)	0				
Label	Value												
Velocity observer gain(--)	0												
Velocity observer bandwidth(ms)	0												
Current response settings(%)	0												

Parameter	Range(Unit)	Description
Velocity observer gain	0~32767	Defaulted to stable gain and bandwidth.
Velocity observer bandwidth	0~32767(ms)	Set = 1 to deactivate.
Current response settings	50~100(%)	Current loop related effective value ratio

7. After the settings are done, use trial run to run the motor for at least 5 cycles.

Trial run

Position	
Setting	
Pr6.04 Jog Speed	500 rpm
Pr6.25 Acceleration of trial running	200 ms/1000rpm
Pr0.04 Inertia ratio	5
Press enter to modify parameters	
Servo Enable	ON
<input type="checkbox"/> External enabling disabled	
Current Position 7.4496 r	
Forward	Reverse
Position 1	Position 2
0.0000	7.4496
Pr6.21 Waiting time of trial running	1000 ms
Pr6.22 Cycling times of trial running	5
No. of cycles completed	5
Run	



Jog speed > 300rpm

Acceleration < 600ms

Position 1 and Position 2 should be around 5r


Interval waiting time between cycles should be < 500ms with at least 5 cycles

8. Performance evaluation




In position range	To set the velocity deviation between target velocity and actual velocity
Arrival counts	Number of times target value is arrived
Overshoot	The difference between target value and actual value. 10%(White) < Overshoot(Yellow) < 100% (Red)
Jitter counts	Detected jitters. Jitter count = 1(Yellow), more than 1(Red). Default(White)
Max. current	Percentage of max. current


Use Scope to get desired waveform by decreasing stiffness value manually.



9. Disable automatic inertia and vibration identification. Confirm to save parameters or restore to previous settings if the tuning setup is not wanted.



Configuration



Most of the parameters settings can be set up in *Configuration*. Please refer to the parameters description chapter in the manual for explanation and further details on each parameter and their functions.

Control Mode

To set up control mode and Model Following Control (MFC) related parameters. Click on drop-down menu of each parameter for functions/selection assignments. Click “OK” after modification

Control Command

Pr0.01 Control mode 9:EtherCAT			
Number	Label	Axis1	Unit
607E	Position Mode	Forward rotation	-
607E	Velocity Mode	Forward rotation	-
607E	Torque Mode	Forward rotation	-
Pr0.00	Model-following bandwidth	0	0.1Hz
Pr0.02.0	Motion Setting	2:Position	-
Pr0.02.1	Load Setting	0:Manual 1:Standard 2:Position	-

OK

Tips

The current configuration has been downloaded. Do you want to save the current settings?

Yes, the configuration has been downloaded and saved permanently;
No, the configuration has been downloaded but it will reset after restarting.


Yes **No**

Click on “Yes” to save modification permanently. It is recommended to back up parameters before modifying crucial parameters.

Click on “No” and parameters will be restored after servo drive is restarted.


Current loop (Torque loop)

To set up current loop (Torque loop) related parameters. Notch filters can be activated if vibration suppression is required. Pr2.01 - Pr2.06 are valid if Pr2.00 adaptive filtering mode is disabled.




Motor Config.

Only for motor with incremental ABZ+Hall UVW encoder. Select motor model on Motor model input and click on “OK” to save motor parameter settings.




Brake Config.

To set up holding brake output signal, activation and delay time.



Limits

To set up positional, torque and velocity limits. Max. motor speed is the min. value of limit set in Pr7.11 and 6080h.



The dialog box is titled "Limit settings". It contains a table with the following data:

Number	Label	Axis1	Unit
607D-01	607D-01 Positive Limit	0	P
607D-02	607D-02 Negative Limit	0	P
Pr5.21	Torque limit selection	0	--
Pr0.13	1st Torque Limit	300	%
Pr5.22	2nd torque limit	300	%
60E0	60E0 Positive Torque Limit	3000	0.1%
60E1	60E1 Negative Torque Limit	3000	0.1%
6072	6072 Max. motor torque	3000	0.1%
6080	6080 Max. motor velocity	6000	rpm
Pr7.11	Motor maximum speed	7000	r/min

Below the table is a note: "Note: Max. motor speed is the min value of the 2." At the bottom right is an "OK" button.

Alarm limits

To set alarm threshold value (value which alarm occurs once exceeded).

Alarm threshold settings

Number	Label	Axis1	Unit
Pr7.25	Temperature setting for fan on	50	°C
Pr7.27	Driver over-temperature alarm threshold setting	105	°C
Pr7.30	Undervoltage threshold value	140	V
Pr7.34	Oversupply threshold value	400	V
Pr7.32	Vent on threshold value settings	380	V
Pr0.16	Regenerative resistance	50	Ω
Pr0.17	Regenerative resistor power rating	75	W
Pr7.35	Relay control mode setting	0	-
Pr7.36	Relay close threshold value	200	V
Pr0.14	Excessive Position Deviation Settings	200	0.1rev

Warning: Set these parameters under professional guidance!

OK Cancel

Electronic Gear Ratio

To set up Pulses per revolution or electronic gear ratio. Calculation formulas are provided.

Electronic Gear Ratio

Pulses Per Revolution 6092 P

Electronic Gear Ratio

Numerator 6091-01

Denominator 6091-02

Lead screw transmission:

Pulses per revolution = Screw lead/pulse equivalent


Gear transmission:

Pulses per revolution = (modulus * number of pinion * Helical Angle * 3.1415927) / (gear ratio * pulse equivalent)

OK


IO Settings

DI/DO signals can be switched on the tab above. DI/DO signals for each channel can be assigned using the drop-down menu on each channel.




Position loop

To set up position loop control related parameters.



Velocity loop

To set up velocity loop control related parameters.



Parameters List

All servo drive parameters are listed in the parameters list. Parameters will be of default value at initial use. Parameters are classified into different categories on the left panel. Please be aware of **recommended range** when modifying the value on **Axis** column and **remarks** of the parameters as some parameter modifications may require servo drive restart to be valid. Admin right may be required for certain parameters.

Manage Parameter								
	Number	Label	Axis1	Min	Max	Default	Unit	Remarks
All Parameters	Pr0.00	Model-following band...	0	0	5000	1	0.1Hz	None
Pr0.Basic Settings	Pr0.01	Control Mode Settings	9	0	9	9		valid after restart pow
Pr1.Gain Adjustment	Pr0.02	Real time Auto Gain A...	0x2	0x0	0x1F	0x2	--	None
Pr2.Vibration Suppression	Pr0.03	Real time auto stiffness...	68	50	81	70	--	None
Pr3.Velocity/Torque Control	Pr0.04	Inertia ratio	250	0	20000	250	%	None
Pr4.I/O Monitoring Settings	Pr0.05	Reserved	0	0	1	0	--	None
Pr5.Extended Settings	Pr0.06	Command polarity inv...	0	0	1	0	--	valid after restart pow
Pr6.Special Settings	Pr0.07	Probe signal polarity ...	3	0	3	3	--	valid after restart pow
Pr7.Factory Settings	Pr0.08	Command pulse coun...	10000	0	8388608	0	--	valid after restart pow
	Pr0.09	Reserved	1	1	1073741...	1	--	None
	Pr0.10	Reserved	1	1	1073741...	1	--	None
	Pr0.11	Encoder pulse output ...	2500	1	65535	2500	--	None
	Pr0.12	Pulse output logic inv...	0	0	1	0	--	None
	Pr0.13	1st Torque Limit	300	0	500	300	%	None
	Pr0.14	Excessive Position D...	200	0	500	200	0.1rev	Encoder unit
	Pr0.15	Absolute Encoder sett...	0	0	32767	0	--	valid after restart pow
	Pr0.16	Regenerative resistance	50	40	500	100	Ω	None
	Pr0.17	Regenerative resistor ...	75	20	5000	50	W	None
	Pr0.18	Reserved	0	0	10000	0	--	None
	Pr0.19	Friction compensation	0	0	1000	0	--	None

	Read parameter files	Read parameter settings save on PC (.lsr files)
	Save parameters	Save current parameter files as .lsr files. Recommended to back up parameter settings before any modification.
	Read from driver	Read parameter settings from driver
	Write to driver	Write parameters to drivers.
	Compare parameters*	Parameters comparison can be made between current parameter settings, saved parameter files and parameter default values.
	Save to driver	Save parameters into drivers.
	Factory reset	Restore all parameters back to factory default
	Help	Parameters description can be found in Motion Studio User Manual


Compare parameter

Parameter values can be compared by clicking on  in Parameters List. “Compare Parameters” window will appear with option to set up parameter 1 and 2 for comparison. Parameters between different axes can also be compared.

Compare parameters

Parameter 1	Current Paramer	Parameter 2	Compare	
Parameter 1	Current Parameter	Parameter 2	Compare	
Show	Axis1	<input type="checkbox"/> Compare axis parameters		
Axis	Parameter Type	Label	Parameter Value 1	Parameter Value 2
1	Pr0.00	Model-following bandwidth	0	1
1	Pr0.03	Real time auto stiffness ad...	68	70
1	Pr0.08	Command pulse counts p...	10000	0
1	Pr0.16	Regenerative resistance	50	100
1	Pr0.17	Regenerative resistor pow...	75	50
1	Pr1.00	1st position loop gain	480	320
1	Pr1.01	1st velocity loop gain	270	180
1	Pr1.02	1st Integral Time Constant ...	210	310
1	Pr1.04	1st Torque Filter Time Con...	84	126
1	Pr1.05	2nd Position Loop Gain	570	380
1	Pr1.06	2nd velocity loop gain	270	180
1	Pr1.09	2nd Torque Filter Time Co...	84	126
1	Pr2.01	1st notch frequency	2000	4000
1	Pr2.04	2nd notch frequency	2000	4000
1	Pr2.07	3rd notch frequency	2000	4000
1	Pr3.12	Acceleration time settings	100	0
1	Pr3.13	Deceleration time settings	100	0
1	Pr4.11	Output selection DO2	0x2	0x3


Performance Tuning




Inertia Ratio Identification

Inertia ratio of the servo product can be automatically identified using “Inertia Ratio Identification”. It is a step-by-step guided operation for performance tuning.

1. Set trial run velocity Pr6.04 and trial run acceleration Pr6.25, click on ‘Download’ to modify parameters. It is recommended to leave the parameters at default values. Then, Tick “External enabling disabled” and click on “Servo on” to enable the servo drive.



2. Click and hold “Positive direction” to start the motor. Current position will show motor position. Click on POS 1 to save current position as starting point. Click and hold “Negative direction” to start the motor again. Click on POS 2 to save current position as ending point. Then, Set the waiting time between each cycle in Pr6.21 and no. of cycles in Pr6.22. Click on‘Run’ and motor will run according to the parameters set.



3. After the calculation is done, inertia ratio will be calculated automatically and click on 'Write'  to enter the calculated value into Pr0.04. Click on "  " to enter Parameters List to check or modify Pr0.04. Then, click on "  " to save parameters to driver.

Inertia ratio measuring

STEP-1

Pr6.04 Jog Speed	<input type="text" value="300"/>	rpm	<input type="button" value="Download"/>
Pr6.25 Acceleration of trial running	<input type="text" value="150"/>	ms/1000rpm	
Default Inertia Ratio	<input type="text" value="250"/>		<input type="button" value="Servo Enable"/> ON

External enabling disabled

STEP-2

	Current <input type="text" value="10.4787"/> r
	<input type="button" value="Positive direction"/> <input type="button" value="Negative direction"/>
	<input type="text" value="0.0912"/> Position 1 <input type="text" value="10.4788"/> Position 2

Pr6.21 Waiting time of trial running	<input type="text" value="300"/> ms	<input type="button" value="Stop"/>
Pr6.22 Cycling times of trial running	<input type="text" value="5"/>	

STEP-3

Inertia Ratio	<input type="text" value="18"/>	<input type="button" value="Write"/>
---------------	---------------------------------	--------------------------------------

Please take note:

1. Trial run velocity and distance should be optimal to prevent any axis from bumping into objects.
2. It is recommended to move only in 1 direction for vertically mounted axis. Take precaution before moving the axis.
3. For applications with higher frictional drag, please set a minimal travel distance.

Gain Adjustment

Gain adjustment can be done automatically or manually. There are options for easy adjustments such as Single Parameter Tuning or One-click Tuning. Please refer to related AC servo drive series user manual for details on gain adjustment. Step-by-step guide to gain adjustment of different modes are available in product user manual. This section is only for introduction to gain and filter parameters tuning interface. Parameters descriptions are available in Help.

Gain Adjustment

Number	Label	Axis1	Unit
Pr02.0	Motion Setting	2:Position	--
Pr02.1	Load Setting	0:Rigid structu...	--
Pr03	Real time auto stif...		--
Pr1.00	1st position loop g...	480	0.1/s
Pr1.01	1st velocity loop g...	270	0.1Hz
Pr1.02	1st Integral Time ...	210	0.1ms
Pr1.03	1st velocity detecti...	15	--
Pr1.04	1st Torque Filter T...	84	0.01ms
Pr1.05	2nd Position Loop...	570	0.1/s
Pr1.06	2nd velocity loop ...	270	0.1Hz
Pr1.07	2nd Integral Time ...	10000	0.1ms

Pr0.01 Control mode

9:EtherCAT


Pr0.04 Inertia ratio

Number	Label	Axis1	Unit
Pr2.00	Adaptive filtering ...	0:Disable auto...	--
Pr2.01	1st notch frequency	2000	Hz
Pr2.02	1st notch bandwid...	2	--
Pr2.03	1st notch depth se...	0	--
Pr2.04	2nd notch frequenc...	2000	Hz
Pr2.05	2nd notch bandwi...	2	--
Pr2.06	2nd notch depth s...	0	--
Pr2.07	3rd notch frequency	2000	Hz
Pr2.08	3rd notch bandwi...	2	--

Click on "OK" to save modified parameters.

Mechanical Analysis

To determine mechanical and set up notch filter parameters to suppress vibration caused by resonance.



To avoid strong vibration, please first set lower excitation amplitude. However, if the set value is too low, data waveform will include some degree of distortion.

If vibration occurs during tests which can't be reduce through lowering electrical current excitation, it might be due to excessive gain. Please lower velocity gain and set notch filter as accordance from the mechanical properties analysis. Or might be due to inertia settings (Pr0.04) is too large, please use optimal inertia ratio value.


Click on "Start" to start mechanical properties analysis. Click on Notch Filter Design to get the identified notch filter settings. Use the arrow keys on the right panel to save the parameters to driver. Notch filter 1 and 2 is available on all servo drive models while notch filter 5 and 6 is model dependent. All analysis can be saved and read as .mch files.

Running




Trial Run

To test run servo products after successfully connected to Motion Studio and initial setup is done. Main power supply and motor/encoder cable need to be connected to use this function.




1. Set jog velocity and acceleration. If unsure, leave both at default value. Press enter for modification of parameters to be valid.
2. Enable servo drive by clicking Servo Enable. **ON** indicates servo drive and motor are enabled.
3. Click and hold “Positive Direction” or “Negative Direction” for motor to rotate in desired direction. Click on Position 1 and Position 2 to set current point as starting and ending point of trial run. It is recommended to have at least 10r (*10 revolutions*) between Position 1 and 2
4. Set Pr6.21 for the time interval between each cycle and no. of cycles of the trial run.
5. Click on “Run” to start the motor. Click on “Stop” to stop the motor or motor will stop after completing the no. of cycles set.

Other related parameters can be found on the right after clicking on “Expand”. Servo drive needs to be enabled. Click on “Fold” to retract these parameters when not needed.




Number	Label
Pr0.02.0	Motion Setting
Pr0.02.1	Load Setting
Pr0.03	Real time auto stiffness adjust...
Pr0.06	Command polarity inversion
Pr3.03	Velocity command input inversi...
Pr1.00	1st position loop gain
Pr1.01	1st velocity loop gain
Pr1.02	1st Integral Time Constant of V...
Pr1.04	1st Torque Filter Time Constant
Pr1.05	2nd Position Loop Gain
Pr1.06	2nd velocity loop gain
Pr1.07	2nd Integral Time Constant of V...
Pr1.09	2nd Torque Filter Time Constant
Pr1.10	Velocity feed forward gain
Pr1.12	Torque feed forward gain
Pr1.15	Position control gain switching ...

Monitor



Scope

To read or save captured data in waveform. Multiple different data of servo drives can be monitored using scope.



①	To read saved waveform files (.csv) To save captured waveform as .csv file.
②	Can monitor up to 6 variables at the same time (Servo drive model dependent)
③	Set trigger source, mode and conditions for waveform capturing to start
④	Set sampling size and its precision according to user's needs.

Alarm

To check error messages, causes and recommended solutions. Clear alarm after handling the error successfully. Historical records of alarms can also be found in this function. Alarms related to motor stops rotating is highlighted in different for users to easily detect the cause of error(s), solve the error and return axis to normal operational status.

Alarm

Current History Cause(s) of motor not rotating

Device	Alarm Code	Alarm label	Clearable	Error Level
Axis1	ErrorD2	No main power supply detected	Yes	2

Click on the error in this list to get error analysis on the table below

Error Analysis

ID	Cause	Check	Handle
1	No main power supply	Verify L1,L2,L3 terminal voltage	1. Increase main power supply voltage : 2. Secure conn...

Error Diagnostic

ID	Label	Value


Please make sure to handle alarm as recommended before clearing

State Monitor


The difference between short interval monitoring and general monitoring is the data sampling time interval. All data/variables can be added or removed from each monitoring list and the time intervals can be modified according to users' needs.

Short Interval monitoring: Sampling time interval of 50-200ms per cycle.

General monitoring: Sampling time interval 300ms up to 5000ms per cycle.




EtherCAT



Object Dictionary

To edit Object Dictionary. Descriptions can be found in Parameters Guide. Object categories can be found on the left panel. Objects can be filtered to make locating specific object easier.



	Read object files	Read object settings save on PC (.obd files)
	Save objects	Save current object files as .obd files. Recommended to back up object settings before any modification.
	Read from driver	Read object settings from driver
	Write to driver	Write objects to drivers.
	Compare objects	Objects comparison can be made between current object settings, saved object files and object default values.
	PDO configuration*	To modify Process Data Objects
	Save to driver	Save objects into drivers.
	Factory reset	Restore all objects back to factory default

PDO configuration

PDO Configuration

Receive PDO Transmit PDO SDO

Label	Index	SubIndex	Bit length
Receive PDO 1	0x1600	0x00	
Control Word	0x6040	0x00	16
Target Position	0x607A	0x00	32
Probe Function	0x60B8	0x00	16
Receive PDO 2	0x1601	0x00	
Control Word	0x6040	0x00	16
Target Position	0x607A	0x00	32
Profile Velocity	0x6081	0x00	32
Profile Acceleration	0x6083	0x00	32
Profile Deceleration	0x6084	0x00	32
Operation Mode	0x6060	0x00	8
Receive PDO 3	0x1602	0x00	
Control Word	0x6040	0x00	16
Target Velocity	0x60FF	0x00	32
Profile Acceleration	0x6083	0x00	32
Profile Deceleration	0x6084	0x00	32
Operation Mode	0x6060	0x00	8
Receive PDO 4	0x1603	0x00	
Control Word	0x6040	0x00	16
Homing Method	0x6098	0x00	8
Limit Switch Velocity	0x6099	0x01	32
Homing Velocity	0x6099	0x02	32
Homing Acceleration	0x609A	0x00	32
Home Offset	0x607C	0x00	32
Operation Mode	0x6060	0x00	8

Add Delete Edit Up Down Save

Tips: Double click to edit PDO


PDO Configuration

Receive PDO Transmit PDO SDO

ID	Index : SubIndex	Label	Value	Bit le...
1	0x1600 - 0x01	Mapping Information 1	0x60400010	32
2	0x1600 - 0x02	Mapping Information 2	0x607A0020	32
3	0x1600 - 0x03	Mapping Information 3	0x60B80010	32
4	0x1600 - 0x04	Number of Entries	3	32
5	0x1601 - 0x01	Mapping Information 1	0x60400010	32
6	0x1601 - 0x02	Mapping Information 2	0x607A0020	32
7	0x1601 - 0x03	Mapping Information 3	0x60B80020	32
8	0x1601 - 0x04	Mapping Information 4	0x60B830020	32
9	0x1601 - 0x05	Mapping Information 5	0x60B840020	32
10	0x1601 - 0x06	Mapping Information 6	0x60600008	32
11	0x1601 - 0x07	Number of Entries	6	32
12	0x1602 - 0x01	Mapping Information 1	0x60400010	32
13	0x1602 - 0x02	Mapping Information 2	0x60F0P0020	32
14	0x1602 - 0x03	Mapping Information 3	0x60B830020	32
15	0x1602 - 0x04	Mapping Information 4	0x60B840020	32
16	0x1602 - 0x05	Mapping Information 5	0x60600008	32
17	0x1602 - 0x06	Number of Entries	5	32
18	0x1603 - 0x01	Mapping Information 1	0x60400010	32
19	0x1603 - 0x02	Mapping Information 2	0x609B80008	32
20	0x1603 - 0x03	Mapping Information 3	0x60990120	32
21	0x1603 - 0x04	Mapping Information 4	0x60990220	32
22	0x1603 - 0x05	Mapping Information 5	0x609A0020	32
23	0x1603 - 0x06	Mapping Information 6	0x607C0020	32
24	0x1603 - 0x07	Mapping Information 7	0x60600008	32
25	0x1603 - 0x08	Number of Entries	7	32
26	0xA00 - 0x01	Mapping Information 1	0x603F0010	32
27	0xA00 - 0x02	Mapping Information 2	0x60410010	32
28	0xA00 - 0x03	Mapping Information 3	0x60610008	32
29	0xA00 - 0x04	Mapping Information 4	0x60640020	32
30	0xA00 - 0x05	Mapping Information 5	0x60B90010	32
31	0xA00 - 0x06	Mapping Information 6	0x60B8A0020	32
32	0xA00 - 0x07	Mapping Information 7	0x60FD0020	32
33	0xA00 - 0x08	Number of Entries	7	32
34	0xA01 - 0x00	Number of Entries	0	32
35	0xC12 - 0x01	SM2 PDO Mapping 0	0x1600	16
36	0xC12 - 0x00	Number of Entries	1	8

402 observer


To monitor control/status word and DI/DO state



Control word		Axis1(6040-0... 0x0000)	Digital input		Axis1(60FD-0... 0x03000000)	Digital output		Axis1(60FE-0... 0x0000)
Bit0: Switch on	<input type="radio"/>		Bit0: Negative limit sw...	<input type="radio"/>		Bit16:Digital output1	<input type="checkbox"/>	
Bit1: Voltage output	<input type="radio"/>		Bit1: Positive limit swit...	<input type="radio"/>		Bit17:Digital output2	<input type="checkbox"/>	
Bit2: Quick stop	<input type="radio"/>		Bit2: HOME	<input type="radio"/>		Bit18:Digital output3	<input type="checkbox"/>	
Bit3: Enable operation	<input type="radio"/>		Bit3: Reserved	<input type="radio"/>		Bit19:Digital output4	<input type="checkbox"/>	
Bit4: Mode specific	<input type="radio"/>		Bit4: Digital input1	<input type="radio"/>		Bit20:Digital output5	<input type="checkbox"/>	
Bit5: Mode specific	<input type="radio"/>		Bit5: Digital input2	<input type="radio"/>		Bit21:Digital output6	<input type="checkbox"/>	
Bit6: Mode specific	<input type="radio"/>		Bit6: Digital input3	<input type="radio"/>		Bit22:Digital output7	<input type="checkbox"/>	
Bit7: Reset error	<input type="radio"/>		Bit7: Digital input4	<input type="radio"/>		Bit23:Digital output8	<input type="checkbox"/>	
Bit8: Halt	<input type="radio"/>		Bit8: Digital input5	<input type="radio"/>		Bit24:Digital output9	<input type="checkbox"/>	
Bit9: Reserved	<input type="radio"/>		Bit9: Digital input6	<input type="radio"/>		Bit25:Digital output10	<input type="checkbox"/>	
Bit10: Reserved	<input type="radio"/>		Bit10: Digital input7	<input type="radio"/>		Bit26:Digital output11	<input type="checkbox"/>	
Bit11: Reserved	<input type="radio"/>		Bit11: Digital input8	<input type="radio"/>		Bit27:Digital output12	<input type="checkbox"/>	
Bit12: Reserved	<input type="radio"/>		Bit12: Digital input9	<input type="radio"/>		Bit28:Digital output13	<input type="checkbox"/>	
Bit13: Reserved	<input type="radio"/>		Bit13: Digital input10	<input type="radio"/>		Bit29:Digital output14	<input type="checkbox"/>	
Bit14: Reserved	<input type="radio"/>		Bit14: Digital input11	<input type="radio"/>		Bit30:Digital output15	<input type="checkbox"/>	
Bit15: Reserved	<input type="radio"/>		Bit15: Digital input12	<input type="radio"/>		Bit31:Digital output16	<input type="checkbox"/>	
Bit0: Ready	<input type="radio"/>		Bit16: Digital input13	<input type="radio"/>		State observation		
Bit1: Switched on	<input type="radio"/>		Bit17: Digital input14	<input type="radio"/>		Target Position(UInt)	607A-00h: 0	
Bit2: Operation enabl...	<input type="radio"/>		Bit18: Reserved	<input type="radio"/>		Position Feedforward(UInt)	60B0-00h: 0	
Bit3: Error	<input checked="" type="radio"/>		Bit19: Reserved	<input type="radio"/>		Actual Position(UInt)	6064-00h: 0	
Bit4: Voltage output	<input checked="" type="radio"/>		Bit20: STO1	<input type="radio"/>		Actual Following Error(UInt)	60F4-00h: 104785	
Bit5: Quick stop	<input type="radio"/>		Bit21: STO2	<input type="radio"/>		Actual Velocity(UInt/s)	606C-00h: 0	
Bit6: Disabled	<input type="radio"/>		Bit22: EDM	<input type="radio"/>		Actual Torque(0..1%)	6077-00h: 0	
Bit7: Warning	<input type="radio"/>		Bit23: Emergency Stop	<input type="radio"/>		Position Command Value(UInt)	6062-00h: 104785	
Bit8: Reserved	<input type="radio"/>		Bit24: INP	<input checked="" type="radio"/>		Velocity Command Value(UInt/s)	606B-00h: 0	
Bit9: Remote	<input type="radio"/>		Bit25: Holding brake	<input checked="" type="radio"/>		Torque Command Value(0..1%)	6074-00h: 0	
Bit10: Target reached	<input checked="" type="radio"/>		Bit26: EXT1	<input type="radio"/>		Operation Mode(-)	6060-00h: 3	
Bit11: Internal limit	<input type="radio"/>		Bit27: EXT2	<input type="radio"/>		Operation Mode Display(-)	6061-00h: 3	
Bit12: Mode specific	<input type="radio"/>		Bit28: Reserved	<input type="radio"/>		Error Code(-)	603F-00h: 0x2212	
Bit13: Mode specific	<input type="radio"/>		Bit29: Reserved	<input type="radio"/>				
Bit14: Reserved	<input type="radio"/>		Bit30: Reserved	<input type="radio"/>				
Bit15: Reserved	<input type="radio"/>		Bit31: Z signal	<input type="radio"/>				

Diagnostics

Operation and Register Operation can be found here



Operation observation			
RPDO bytes:	<input type="text" value="8"/>	Synchronization cycle time:	<input type="text" value="0"/> ns
TPDO bytes:	<input type="text" value="19"/>	SM2 processing time (maximum):	<input type="text" value="0"/> ns
SM2 lost times:	<input type="text" value="0"/>	SM3 processing time (maximum):	<input type="text" value="0"/> ns
Sync lost times:	<input type="text" value="0"/>	SM2-Sync interval (minimum):	<input type="text" value="-1"/> ns
Synchronization overflow times:	<input type="text" value="0"/>	Sync0 offset time (maximum):	<input type="text" value="0"/> ns
Synchronization offset too short times:	<input type="text" value="0"/>	Synchronization type:	<input type="text" value="0: Free Run"/>
Synchronous drift overload times:	<input type="text" value="0"/>		

Register observation			
Port 0 invalid frame count (300h):	<input type="text" value="0"/>	Port 1 invalid frame count (302h):	<input type="text" value="0"/>
Port 0 receive error count (301h):	<input type="text" value="0"/>	Port 1 receive error count (303h):	<input type="text" value="0"/>
Port 0 forwarding error count (308h):	<input type="text" value="0"/>	Port 1 forwarding error count (309h):	<input type="text" value="0"/>
EPU error count (30ch):	<input type="text" value="0"/>	PDI error count (30dh):	<input type="text" value="0"/>
Port 0 link loss count (310h):	<input type="text" value="0"/>	Port 1 link loss count (311h):	<input type="text" value="0"/>